



Instruction of resetting **mechanical limiters**



ROLLER SHUTTERS

General Recommendations:

The installation and configuration of the blind should be carried out only by a trained installation team. It is essential to comply with all relevant health and safety regulations, particularly those concerning work at height and with electrical equipment.

Resetting Instructions using an Aluprof motor as an example

Setting the Lower Limit:

1. Press the DOWN button on the remote control.
2. Turn the upper (white) limit switch in the minus direction until the blind comes to a complete stop.
3. Press the DOWN button again to confirm that the blind no longer moves.
4. If the blind does not move – gently turn the upper limit switch in the plus (“+”) direction until the blind reaches the desired bottom position.

Setting the Upper Limit:

5. Press the UP button on the remote control.
6. Turn the lower (red) limit switch in the minus direction until the blind comes to a complete stop.
7. Press the UP button again to confirm that the blind no longer moves.
8. If the blind does not move – gently turn the lower limit switch in the plus (“+”) direction until the blind reaches the desired top position.

At this stage, the mechanical limit switches should be correctly set.



Set the upper limit so that the bottom slat of the roller shutter remains visible when the curtain is fully rolled up – this helps prevent damage and avoids the need for reinstallation. Take note of the seal on the bottom slat, indicated by the red arrow in the photo on the left

